



SCOTT PLASMA ADAPTER

INSTALLATION GUIDE



U-PLATE

Remove the original tower, use Delta Speed riser to reach the desired height (order separately), use the M6 original screws to assemble the adapter on top of the risers, if any, or on the cockpit (6Nm).

Assemble the Delta speed U plate on top of the adapter with the two screws (6Nm), there are 2 holes on the side in case of shimano di 2 cables.



RISERS NOT INCLUDED





AEROBAR + U PLATE

INSTALLATION GUIDE

M5 X 14mm
TORQUE 5Nm



Use the Thread lock
on the screw's thread
(Just few drops)





AEROBAR HANDLE GRIP

+ GPS COMPUTER

INSTALLATION GUIDE



Use the Thread lock
on the screw's thread
(Just few drops)

